

北京中显电子有限公司

图形点阵液晶显示模块资料

ZX240128A- V3.0

公司地址:海淀区中关村大街32号和盛大厦811室

电话:010-82626833 52926620


传真:010-52926621

网址:www.zxlcd.com

目 录

- (一) [概述](#)
- (二) [外形尺寸](#)
- (三) [模块结构框图](#)
- (四) [模块的外部接口](#)
- (五) [指令说明](#)
- (六) [电气参数](#)
- (七) [IC 功能描述](#)
- (八) [应用举例](#)

三、硬件结构图



四、模块的外部接口

外部接口信号如下表 2 所示:

表 2

Pin no	Symbol	Level	Function
1	FG	0V	Frame ground
2	Vss	0V	Ground
3	VDD	5.0V	Supply voltage for logic
4	V0	-	Operating voltage for LCD drive
5	/WR	L	Write signal
6	/RD	L	Read signal
7	/CE	L	Chip enable signal
8	C/D	H/L	H: Instruction code L: Data
9	/RESET	L	Reset signal
10	DB0	H/L	Data bit 0
11	DB1	H/L	Data bit 1
12	DB2	H/L	Data bit 2
13	DB3	H/L	Data bit 3
14	DB4	H/L	Data bit 4
15	DB5	H/L	Data bit 5
16	DB6	H/L	Data bit 6
17	DB7	H/L	Data bit 7
18	FS	H/L	Font select signal (H:5X8 dots; L:8X8 dots)
19	VOUT/A		
20	LED+/K	-	LED Backlight
21	LED-		LED Backlight

兼容香港精电 MGLS-240128TA VP240128TA-01 当 19 脚为 LED 背光正 A 时, 20 脚为 LED 背光负 K

五、IC 说明及指令表

T6963C is LCD controller designed to be used for control LCD driver LCD driver LSIs and display data Memory, It has an 8 bit parallel data bus

And control lines for reading or writing through a MPU I/F.

It has 128 words character generator ROM with the capability to control External display RAM of up to 128K bytes. Allocation of text, graphics And external generator RAM can be easily made and the display window can Be freely moved within the allocated memory range.

It supports a very board range of LCD formats by selecting different Combinations on a set of programmable inputs. It can be used in text, graphic Modes and has various attribute functions.

指令表:

表 2

COMMAND	CODE	D1	D2	FUNCTION
Register Set	00100001	X address	Y address	Cursor pointer set
	00100010	Data	00H	Off register
	00100100	Low address	High address	Address pointer set
Control Word set	01000000	Low address	High address	Text home address set
	01000001	Columns	00H	Text area set
	01000010	Low address	High address	Graphic home address set
	01000011	Columns	00H	Graphic area set
Mode set	1000x000	-	-	"OR" mode
	1000x001	-	-	"EXOR" mode
	1000x011	-	-	"AND" mode
	1000x100	-	-	"Text attribute" mode
	10000xxx	-	-	Internal CGROM mode
	10001xxx	-	-	External CGRAM mode
Display Mode	10010000	-	-	Display off
	1001xx10	-	-	Cursor on, blink off
	1001xx11	-	-	Cursor on, blink on
	100101xx	-	-	Text on, graphic off
	100110xx	-	-	Text off, graphic on
	100111xx	-	-	Text on, graphic on
Cursor Pattern Select	10100000	-	-	1 line cursor
	10100001	-	-	2 line cursor
	10100010	-	-	3 line cursor
	10100011	-	-	4 line cursor
	10100100	-	-	5 line cursor
	10100101	-	-	6 line cursor
	10100110	-	-	7 line cursor
	10100111	-	-	8 line cursor
Data auto Read/write	10110000	-	-	Data auto write set
	10110001	-	-	Data auto read set
	10110010	-	-	Auto reset
Data read Write	11000000	Data	-	Data write and ADP increment
	11000001	-	-	Data read and ADP increment
	11000010	Data	-	Data write and ADP decrement
	11000011	-	-	Data read and ADP decrement
	11000100	Data	-	Data write and ADP no variable
	11000101	-	-	Data read and ADP no variable
Screen peek	11100000	-	-	Screen peek
Screen copy	11101000	-	-	Screen copy
	11110XX	-	-	Bit reset

Bit Set/Reset	11111XXX	-	-	Bit set
	1111X000	-	-	Bit 0(LSB)
	1111X001	-	-	Bit 1
	1111X010	-	-	Bit 2
	1111X011	-	-	Bit 3
	1111X100	-	-	Bit 4
	1111X101	-	-	Bit 5
	1111X110	-	-	Bit 6
	1111X111	-	-	Bit 7(MSB)

六、电气参数

1. ABSOLUTE MAXIMUM RATING

Item	Symbol	Condition	Min	Typ	Max	Unit
Supply Voltage(logic)	VDD-VSS	-	-0.3	-	7	V
Supply Voltage(LCD Drive)	VDD-VO	-	VDD+0.3	-	VDD-0.3	V
Input Voltage	VI	-	-0.3	-	VDD+0.3	V
Operating Temperature	Topr	-	-10	-	+55	° C
Storage Temperature	Tstg	-	-20	-	+60	° C

2. OPTICAL DATA Ta=25° C

Item	Symbol	Condition	Standard Value			Unit	
			min	typ	max		
Supply voltage(Logic)	VDD-VSS	-	4.75	5	5.25	V	
Supply voltage(LCD Drive)	VDD-VO	-	-	-	-	V	
Supply current	IDD	-	-	12.0	17.0	mA	
	IO	-	-	1.8	2.5	mA	
EL Backlight current	IEL	-	-	100	-	mA	
Input high voltage	VIH	High level	0.7VDD	-	VDD	V	
Input low voltage	VIL	Low level	0	-	0.3VDD	V	
Supply voltage for LCD Drive (1/80 duty)	VDD-VO	Ta=0° C	14.2	14.5	14.8	V	
		Ta=25° C	13.3	13.6	13.9	V	
		Ta=50° C	12.3	12.6	12.9	V	
Contrast Ratio	CR		-	4	-	-	
Viewing Angle	-	CR≥2	θ	-10	-	20	deg
			φ	60	-	120	deg
Response Time (rise)	Tr	Note 1	Ta=25°	-	130	200	ms
Response Time (delay)	Td	Note 2	Ta=25°	-	150	230	ms

NOTE 1: Required time for blackening ratio of segment goes up from 0% to 90% when Wave from is switched from one selected one ($\theta = 10^\circ$, $\phi = 90^\circ$)


Note 2: Required time for blackening ratio of segment goes down from 100% to 10% When wave from is switched from one selected one ($\theta = 10^\circ$, $\phi = 90^\circ$)

3. TIMING CHARACTERISTICS

Item	Symbol	Min	Max	Unit
Operating frequency	fSCP	-	2.75	MHZ
SCP pulse width	Tcwh, Tcwl	150		ns
SCP rise/fall time	Tr	-	30	ns
LP set up time	Tlsu	150	290	ns
LP hold time	Tlhd	5	40	ns

Data set up time	Tdsu	170	-	ns
Data hold time	Tdhd	80	-	ns
FR delay time	Td	0	90	ns
CDATA set up time	Tcsu	450	850	ns
CDATA hold time	Tchd	450	950	ns


Condition: DV=+5.0V ± 10%, Ta=-10~+70° C



驱动波形图

4. INTERFACE TIMING

Item	Symbol	Min	Max	Unit
C/D set up time	Tcds	100	-	ns
C/D hold time	Tcdh	10	-	ns
CE, RD, WR pulse width	Tce, Trd, Twr	80	-	ns
DATA set up time	Tds	80	-	ns
DATA hold time	Tdh	40	-	ns
Access time	Tacc	-	150	ns
Output hold time	Toh	10	50	ns



读写时序图

5.EL Backlight Electrical Characteristics

Ta=25° C VDD=5V

Symbol	Parameter	Min	Type	Max	Units
IIN	VDD supply current	10		150	mA
VA-B	Output voltage across lamp	37	40	43	V
		75	80	85	V
FEL	VA-B output drive frequency	600	800	1000	V
VDD	Supply voltage	4.5		12	V
CL	Load capacitance	0		25	nF
TA	Operating temperature	0		50	° C

Note: EL Backlight with white lamp.

七、功能描述

7.1 STATUS READ

Before sending data(read/write),command it is necessary to check the Status.

Status check

Status of T6963c can read from data lines.

/RD L

/WR H

/CE L

C/D H

D0~D7 Status word

T6963C status word format is following

MSB				LSB			
STA7	STA6	STA5	STA4	STA3	STA2	STA1	STA0
D7	D6	D5	D4	D3	D2	D1	D0

STA0	Check capability of command execution	0:Disable 1:Enable
STA1	Check capability of data read/write	0:Disable 1:Enable
STA2	Check capability of auto mode data read	0:Disable 1:Enable
STA3	Check capability of auto mode data write	0:Disable 1:Enable
STA4	Not use	
STA5	Check capability of controller operation	0:Disable 1:Enable
STA6	Error flag. Using screen peek/copy command	0:No error 1:error
STA7	Check the condition blink	0:Disable 1:Enable

Note 1:It is necessary to check STA0 and STA1 at the same time, The error

Is happened by sending data at executing command.

2:The status check will be enough to check STA0/STA1.

3:STA2/STA3 are valid in auto mode STA0/STA1 are invalid.


Status checking flow:



7.2 DATA SET

In T6963C, the data have been set and command executes.

The order of procedure of command sending



Note: In case of over 2 data sending, valid).

7.31 Description of command

1. Register set

CODE	HEX	FUNCTION	D1	D2
00100001	21H	Cursor pointer set	X address	Y address
00100010	22H	Offset register set	Data	00H
00100100	24H	Address pointer set	Low address	High address

(1) Cursor pointer set

The position of cursor is specified by X address. The cursor position is moved only by this command. The cursor pointer doesn't have the function of increment and decrement. The shift of cursor set by this command. X address, Y address are specified following.

X address 00H - - - - 4FH (Low 7bits are valid)

Y address 00H - - - - 1FH (Low 5bits are valid)

1 Screen drive

X address 00H - - - - 4FH

Y address 00H - - - - 0FH

(2) Offset register set

The offset register is used to determine external character generator RAM area.

T6963C has 16 bits address lines as follow:

MSB											LSB				
Ad15	Ad14	Ad13	Ad12	Ad11	Ad10	Ad9	Ad8	Ad7	Ad6	Ad5	Ad4	Ad3	Ad2	Ad1	Ad0

The upper 5 bits (ad15 - ad11) are determined by offset register. The

Middle 8 bits (ad10 - ad3) are determined by character code. The


Lower 3 bit (ad2 - ad0) are determined by vertical counter. The

Lower 5 bit of D1(data) are valid. The data format of external character Generator RAM.

(3) Address pointer set

The address pointer set command is used to indicate the start address for writing (or reading) to external RAM.

The flow chart address pointer set command



7.32 Control word set

CODE	HEX	FUNCTION	D1	D2
01000000	40H	Text home address set	Low address	High address
01000001	41H	Text area set	Columns	00H
01000010	42H	Graphic home address set	Low address	High address
01000011	43H	Graphic area set	Columns	00H

The home address and column size are defined by this command

(1) Text home address and area set

The starting address of external display RAM for text display is Defined by this command. The text home address shows the left end and Most upper position .

The relationship of external display RAM address and display position

Example:

Text home address: 0000H
 Text area: 00A0H
 MD2=0, MD3=0: 80 COLUMN
 DUAL=0, MDS=1, MD0=1, MD1=0: 28 LINES

Display plane:

0000H	0001H	- - - - -	004EH	004FH	1 Line
00A0H	00A1H	- - - - -	00EEH	00EFH	2 Line
:	:	:	:	:	:
:	:	:	:	:	:
:	:	:	:	:	:
10E0H	10E1H	- - - - -	112EH	112FH	28 Lines

(2) Graphic home address and area set

The starting address of external display RAM for Graphic display is Defined by this command. The graphic home address shows the left end most Upper line.

The relationship of external display RAM address and display position.

Example:
 Graphic home address: 0000H
 Graphic area: 0020H
 MD2=H, MD3=H: 32 COLUMNS
 DUAL=H, MDS=L, MDO=H, MD1=H: 2 LINES
 Example:
 Display plane:

0000H	0001H	-----	001EH	001FH
0020H	0021H	-----	003EH	003FH
⋮	⋮	⋮	⋮	⋮
⋮	⋮	⋮	⋮	⋮
01E0H	01E1H		01FEH	01FFH

7.33 MODE SET

The display mode is defined by this command. The display mode don't have changed until to send next this command. Logically "OR", "EXOR", "AND" of text and graphic display can be displayed. When internal character generator mode is selected, character code 00H - 7FH are selected from built-in character generator ROM. The character code 80H - FFH are automatically selected external character generator RAM. NOTE: Only text display is attributed, because attributed data is located.

Attribute function

"Reverse display", "Character blink" and "Inhibit" are called "Attribute". The attribute data is written in the graphic area defined by control word set command. The mode set command selects text display only and graphic the mode set command selects text display only and graphic display cannot be displayed. The attribute data of the 1st character in text area


is written at the 1st byte in graphic area, and attribute data of n-th byte in graphic area. Attribute function is defined as follow.

Attribute RAM 1byte

X	X	X	X	D3	D2	D1	D0
---	---	---	---	----	----	----	----

X: don't care

D3	D2	D1	D0	FUNCTION
0	0	0	0	Normal display
0	1	0	1	Reverse display
0	0	1	1	Inhibit display
1	0	0	0	Blink of normal display
1	1	0	0	Blink of reverse display
1	0	1	1	Blink of inhibit display



7.34 DATA AUTO READ/WRITE

CODE	HEX	FUNCTION	OPERAND
10110000	B0H	Data auto write set	-
10110001	B1H	Data auto read set	-

10110010	B2H	Auto reset	-
----------	-----	------------	---

This command is convenient to send full screen data from external display RAM. After setting auto mode, "Data write(or read)" command is not necessary between each data. "Data auto write (or read)" command should follow the "Address pointer set" and address pointer is automatically increment by + 1 after each data. After sending (or receiving) all data "Auto reset" is necessary to return normal operation because all data is regarded "Display data" and no command can be accepted in the auto mode.


Note: status check for auto mode(STA2, STA3 should be checked between each Data. Auto reset should be performed after checking (STA3=1 STA2=1)

7.35 DATA READ WRITE

CODE	HEX	FUNCTION	OPERAND
11000000	C0H	Data write and ADP increment	Data
11000001	C1H	Data read and ADP increment	Data
11000010	C2H	Data write and ADP decrement	Data
11000011	C3H	Data read and ADP decrement	Data
11000100	C4H	Data write and ADP nonvariable	Data
11000101	C5H	Data read and ADP nonvariable	Data

This command is used for data write from MPU to external display RAM, AND data read external display RAM to MPU. Data write/data read should be executed after setting address by address pointer set command. Address Pointer can be automatically increment by setting this command.

Note: this command is necessary for each 1 byte data. Please refer following flow chart.



NOTE:

- (1) After power on, it is necessary to reset. /RESET is kept "L" between 5 CLOCK up(oscillation clock).
- (2) When /HALT has been "L", the oscillation is stopped. It is necessary To turn off power supply for LCD, because LCD goes down by DC bias.
- (3) The HALF function contains the RESET function.
- (4) After state of RESET/HALT.

TERMINAL	HALT	RESET
D0-D7	F	F
D0-d7	F	F
R/w	H	H
/ce	H (NOTE 1)	H (NOTE 1)
Ad0-ad15	H (NOTE 2)	H (NOTE 2)

/ce0, /ce1	H (NOTE 1)	H (NOTE 1)
ED, HOD	Final Data	Final Data
HSCP	L	L
LP	L	L
CDATA	H	H
FR	H	H
CH1	L	K0
CH2	L	VEND
DSPON	L	L
X0	H	OSC CLOCK

H: Level H

L: Level L

F: Floating (High impedance)

K0: Internal state (TEXT data access) normally open


VEND: End signal of V-counter (Line count) if MDS=H, T2=L,
HEND (end signal of H-count) normally open.

Note 1: In Attribute mode, H or L by state of Graphinc pointer.

Note 2: In Attribute mode, DATA of Graphinc pointer.

八、应用举例

ZX240128A 与单片机 8031 的一种接口如图. 所示:



注: V0 为液晶驱动电压。此图为模块内自带负压的示例

```

ORG      0000H
AJMP    MAIN
ORG      0003H
AJMP    ZHONGDUAN
ORG      0035H
ZHONGDUAN:
HERE:   SJMP  HERE
RET

```

```

*****
,
DATA1   EQU    30H      ;第一参数单元
DATA2   EQU    31H      ;第二参数/数据单元
COMMAND EQU    32H      ;指令代码单元
C_ADD   EQU    8100H    ;指令通道地址

```

```

D_ADD EQU 8000H ;数据通道地址
LI1 EQU 33H
LI2 EQU 34H
;*****
BUSY1:
PUSH DPH
PUSH DPL
MOV DPTR,#C_ADD
MOVBX A,@DPTR
POP DPL
POP DPH
RET
;*****
BUSY: LCALL BUSY1
JNB ACC.0, BUSY1
JNB ACC.1, BUSY1
RET
;*****
WRITE_COMMAND: PUSH DPH
PUSH DPL
LCALL BUSY
MOV A,COMMAND
MOV DPTR,#C_ADD
MOVBX @DPTR,A
POP DPL
POP DPH
RET
WRITE_DATA:
PUSH DPH
PUSH DPL
LCALL BUSY
MOV A,DATA2
MOV DPTR,#D_ADD
MOVBX @DPTR,A
POP DPL
POP DPH
RET

MS40: MOV R7,#0E8H
MS2: MOV R6,#0FFH
MS1: DJNZ R6,MS1
DJNZ R7,MS2
RET
DELAY: MOV R5,#05H
DELAY1: LCALL MS40
DJNZ R5,DELAY1
RET
;*****
MAIN:
MOV SP,#20H
MOV P3,#0FFH
SETB EA
SETB EX0
SETB IT0
MOV COMMAND,#90H
LCALL WRITE_COMMAND
LCALL MS40
MOV DATA2,#00H
LCALL WRITE_DATA
MOV DATA2,#00H

```

```

LCALL WRITE_DATA
MOV COMMAND,#40H ;文本显示区首地址设置
LCALL WRITE_COMMAND
; MOV DATA2,#20H
MOV DATA2,#20H
LCALL WRITE_DATA
MOV DATA2,#00H
LCALL WRITE_DATA
MOV COMMAND,#41H ;文本显示区宽度设置
LCALL WRITE_COMMAND

MOV DATA2,#00H
LCALL WRITE_DATA
MOV DATA2,#08H
LCALL WRITE_DATA
MOV COMMAND,#42H ;图形显示区首地址设置
LCALL WRITE_COMMAND

MOV DATA2,#1EH
LCALL WRITE_DATA
MOV DATA2,#00H
LCALL WRITE_DATA
MOV COMMAND,#43H ;图形显示宽度设置
LCALL WRITE_COMMAND

; MOV COMMAND,#0A1H ;光标形状
; LCALL WRITE_COMMAND

MOV COMMAND,#80H ;逻辑或,用 CGROM
LCALL WRITE_COMMAND

MOV COMMAND,#9CH ; 启动文本.图形.光标显示
LCALL WRITE_COMMAND

```

```

;*****888

```

```

;显示全屏

```

```

MOV DATA2,#00H
LCALL WRITE_DATA
MOV DATA2,#00H
LCALL WRITE_DATA
MOV COMMAND,#24H
LCALL WRITE_COMMAND
MOV R3,#00H
MOV COMMAND,#0B0H
LCALL WRITE_COMMAND
MOV R4,#20H

```

```

YY1:

```

```

NOP
YY: MOV A,#0FFH
MOV DATA2,A
LCALL WRITE_DATA
DJNZ R3,YY
DJNZ R4,YY1
MOV COMMAND,#0B2H
LCALL WRITE_COMMAND
LCALL MS40

```

```

;*****

```

```

CLEAR1:
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    COMMAND,#24H      ;显示地址设置
LCALL  WRITE_COMMAND
MOV    R3,#00H
MOV    R4,#20H
MOV    COMMAND,#0B0H    ;自动写入
LCALL  WRITE_COMMAND
M1:
NOP
M:  MOV    A,#00H
    MOV    DATA2,A
    LCALL  WRITE_DATA
    DJNZ  R3,M
    DJNZ  R4,M1
    MOV    COMMAND,#0B2H ;推出自动写入
    LCALL  WRITE_COMMAND

```

```
; *****
```

```
;显示字库
```

```

MOV    R3,#00H
MOV    R4,#7FH
MOV    COMMAND,#0B0H    ;自动写入
LCALL  WRITE_COMMAND
MOV    A,#0FFH          ;写入英文字库
L:  INC  A
    MOV  DATA2,A
    LCALL WRITE_DATA
    DJNZ R4,L
    MOV  COMMAND,#0B2H  ;退出自动写入
    LCALL WRITE_COMMAND
    LCALL DELAY

```

```
;#####
```

```
; 写 CGROM 80H
```

```

MOV    DATA2,#03H
LCALL  WRITE_DATA
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    COMMAND,#22H
LCALL  WRITE_COMMAND

MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    DATA2,#1CH
LCALL  WRITE_DATA
MOV    COMMAND,#24H
LCALL  WRITE_COMMAND

```



```

MOV R2,#2
MOV R0,#0FFH
MOV COMMAND,#0B0H
LCALL WRITE_COMMAND
MOV DPTR,#TEST
LL2: NOP
LL: CLR A
MOV A,@A+DPTR
MOV DATA2,A
LCALL WRITE_DATA
INC DPTR
SETB P1.5
DJNZ R0,LL
DJNZ R2,LL2
MOV DATA2,#0B2H
LCALL WRITE_DATA
SETB P1.4

;#####
MOV DATA2,#00H
LCALL WRITE_DATA
MOV DATA2,#00H
LCALL WRITE_DATA
MOV COMMAND,#24H ;显示地址设置€
LCALL WRITE_COMMAND

MOV COMMAND,#0B0H
LCALL WRITE_COMMAND
MOV R2,#2
TIAO1: MOV R1,#255
MMM: MOV DATA2,#80H
LCALL WRITE_DATA
DJNZ R1,MMM
DJNZ R2,TIAO1
MOV COMMAND,#0B2H
LCALL WRITE_COMMAND
LCALL DELAY

MOV COMMAND,#0B0H
LCALL WRITE_COMMAND
MOV DATA2,#00H
LCALL WRITE_DATA
MOV DATA2,#00H
LCALL WRITE_DATA
MOV COMMAND,#24H ;显示地址设置€
LCALL WRITE_COMMAND
MOV R2,#2
TIAO2: MOV R1,#255
MMM1: MOV DATA2,#81H
LCALL WRITE_DATA
DJNZ R1,MMM1
DJNZ R2,TIAO2
MOV COMMAND,#0B2H
LCALL WRITE_COMMAND
LCALL DELAY

```

```

MOV    COMMAND,#0B0H
LCALL  WRITE_COMMAND
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    COMMAND,#24H      ;显示地址设置€
LCALL  WRITE_COMMAND
MOV    R2,#2
TIAO3: MOV    R1,#255
MMM2:  MOV    DATA2,#82H
        LCALL WRITE_DATA
        DJNZ  R1,MMM2
        DJNZ  R2,TIAO3
        MOV    COMMAND,#0B2H
        LCALL  WRITE_COMMAND
        LCALL  DELAY

```

```

MOV    COMMAND,#0B0H
LCALL  WRITE_COMMAND
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    COMMAND,#24H      ;显示地址设置€
LCALL  WRITE_COMMAND
MOV    R2,#2
TIAO4: MOV    R1,#255
NN:    MOV    DATA2,#83H
        LCALL WRITE_DATA
        DJNZ  R1,NN
        DJNZ  R2,TIAO4
        MOV    COMMAND,#0B2H
        LCALL  WRITE_COMMAND
        LCALL  DELAY

```

```

MOV    COMMAND,#0B0H
LCALL  WRITE_COMMAND
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    DATA2,#00H
LCALL  WRITE_DATA
MOV    COMMAND,#24H      ;显示地址设置€
LCALL  WRITE_COMMAND
MOV    R2,#2
TIAO5: MOV    R1,#255
NN1:   MOV    DATA2,#84H
        LCALL WRITE_DATA
        DJNZ  R1,NN1
        DJNZ  R2,TIAO5
        MOV    COMMAND,#0B2H
        LCALL  WRITE_COMMAND
        LCALL  DELAY

```

```

MOV    COMMAND,#0B0H
LCALL  WRITE_COMMAND
MOV    DATA2,#00H

```

```

    LCALL WRITE_DATA
    MOV DATA2,#00H
    LCALL WRITE_DATA
    MOV COMMAND,#24H ;显示地址设置€
    LCALL WRITE_COMMAND
    MOV R2,#2
TIAO6: MOV R1,#255
NN2:   MOV DATA2,#85H
    LCALL WRITE_DATA
    DJNZ R1,NN2
    DJNZ R2,TIAO6
    MOV COMMAND,#0B2H
    LCALL WRITE_COMMAND
    LCALL DELAY

```

```

    MOV DATA2,#00H
    LCALL WRITE_DATA
    MOV DATA2,#00H
    LCALL WRITE_DATA
    MOV COMMAND,#24H ;显示地址设置
    LCALL WRITE_COMMAND
    MOV R3,#00H
    MOV R4,#20H
    MOV COMMAND,#0B0H ;自动写入
    LCALL WRITE_COMMAND
MM1:  MOV R4,#20H
MM:   MOV A,#00H
    MOV DATA2,A
    LCALL WRITE_DATA
    DJNZ R4,MM
    DJNZ R3,MM1
    MOV COMMAND,#0B2H ;推出自动写入
    LCALL WRITE_COMMAND

```

#####

```

TIAN:
    MOV DATA2,#00H ;显示地址
    LCALL WRITE_DATA
    MOV DATA2,#08H
    LCALL WRITE_DATA
    MOV COMMAND,#24H
    LCALL WRITE_COMMAND

    MOV COMMAND,#0B0H
    LCALL WRITE_COMMAND
    MOV R2,#10H
    MOV R1,#000H
    MOV DPTR,#TIANSHI
SSS:  NOP
SSS1: CLR A
    MOVC A,@A+DPTR
    MOV DATA2,A
    LCALL WRITE_DATA
    INC DPTR
    DJNZ R1,SSS1
    DJNZ R2,SSS
    MOV COMMAND,#0B2H

```

LCALL WRITE_COMMAND
LCALL DELAY
LJMP MAIN

TIANSHI:

DB 0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH
DB 0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,080H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,001H,080H,020H,010H,080H,004H,000H,000H,040H,010H,000H,001H,000H
DB 010H,000H,004H,000H,020H,010H,080H,004H,000H,000H,040H,010H,000H,001H,000H,010H
DB 000H,001H,081H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H,0BFH,080H,090H,01FH
DB 0FEH,001H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H,0BFH,080H,090H,01FH,0FDH
DB 0FDH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H,090H,000H,004H,07DH
DB 024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H,090H,000H,005H,091H,0FCH
DB 050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H,024H,011H,0FCH,050H
DB 080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H,025H,090H,000H,078H,080H
DB 044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F4H,010H,000H,078H,080H,044H
DB 020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F5H,093H,0FEH,097H,0FCH,044H,020H
DB 004H,020H,0FFH,085H,021H,004H,004H,000H,004H,013H,0FEH,097H,0FCH,044H,020H,004H
DB 020H,0FFH,085H,021H,004H,004H,000H,005H,0FCH,040H,090H,020H,07FH,0E3H,0FFH,0F1H
DB 041H,004H,0BFH,008H,043H,08FH,0C4H,07CH,040H,090H,020H,07FH,0E3H,0FFH,0F1H,041H
DB 004H,0BFH,008H,043H,08FH,0C5H,093H,0FCH,018H,020H,044H,020H,004H,002H,07FH,004H
DB 0A8H,090H,041H,008H,044H,013H,0FCH,018H,020H,044H,020H,004H,002H,07FH,004H,0A8H
DB 090H,041H,008H,045H,092H,094H,037H,0FCH,044H,020H,004H,004H,041H,004H,0A9H,000H
DB 080H,008H,044H,012H,094H,037H,0FCH,044H,020H,004H,004H,041H,004H,0A9H,000H,080H
DB 008H,045H,092H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H,0AAH,000H,090H,00FH
DB 0C4H,012H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H,0AAH,000H,090H,00FH,0C5H
DB 09AH,094H,011H,020H,044H,000H,004H,000H,041H,005H,024H,001H,008H,008H,044H,01AH
DB 094H,011H,020H,044H,000H,004H,000H,041H,005H,024H,001H,008H,008H,045H,0E2H,094H
DB 010H,020H,004H,008H,004H,000H,041H,004H,022H,002H,004H,000H,004H,062H,094H,010H
DB 020H,004H,008H,004H,000H,041H,004H,022H,002H,004H,000H,005H,082H,094H,010H,0A0H
DB 004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,014H,002H,094H,010H,0A0H,004H
DB 008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,015H,082H,00CH,010H,040H,003H,0F8H
DB 008H,000H,043H,004H,020H,082H,002H,000H,008H,002H,00CH,010H,040H,003H,0F8H,008H
DB 000H,043H,004H,020H,082H,002H,000H,009H,080H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,001H,080H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,001H,080H,020H,010H,080H,004H,000H,000H,040H,010H,000H,001H,000H,010H,000H
DB 004H,000H,020H,010H,080H,004H,000H,000H,040H,010H,000H,001H,000H,010H,000H,001H
DB 081H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H,0BFH,080H,090H,01FH,0FEH,001H
DB 024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H,0BFH,080H,090H,01FH,0FDH,0FDH,024H
DB 057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H,090H,000H,004H,07DH,024H,057H
DB 0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H,090H,000H,005H,091H,0FCH,050H,080H
DB 07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H,024H,011H,0FCH,050H,080H,07FH
DB 0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H,005H,090H,000H,078H,080H,044H,020H
DB 006H,000H,041H,005H,021H,002H,008H,03FH,0F4H,010H,000H,078H,080H,044H,020H,006H
DB 000H,041H,005H,021H,002H,008H,03FH,0F5H,093H,0FEH,097H,0FCH,044H,020H,004H,020H
DB 0FFH,085H,021H,004H,004H,000H,004H,013H,0FEH,097H,0FCH,044H,020H,004H,020H,0FFH
DB 085H,021H,004H,004H,000H,005H,0FCH,040H,090H,020H,07FH,0E3H,0FFH,0F1H,041H,004H

DB 0BFH,008H,043H,08FH,0C4H,07CH,040H,090H,020H,07FH,0E3H,0FFH,0F1H,041H,004H,0BFH
DB 008H,043H,08FH,0C5H,093H,0FCH,018H,020H,044H,020H,004H,002H,07FH,004H,0A8H,090H
DB 041H,008H,044H,013H,0FCH,018H,020H,044H,020H,004H,002H,07FH,004H,0A8H,090H,041H
DB 008H,045H,092H,094H,037H,0FCH,044H,020H,004H,004H,041H,004H,0A9H,000H,080H,008H
DB 044H,012H,094H,037H,0FCH,044H,020H,004H,004H,041H,004H,0A9H,000H,080H,008H,045H
DB 092H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H,0AAH,000H,090H,00FH,0C4H,012H
DB 094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H,0AAH,000H,090H,00FH,0C5H,09AH,094H
DB 011H,020H,044H,000H,004H,000H,041H,005H,024H,001H,008H,008H,044H,01AH,094H,011H
DB 020H,044H,000H,004H,000H,041H,005H,024H,001H,008H,008H,045H,0E2H,094H,010H,020H
DB 004H,008H,004H,000H,041H,004H,022H,002H,004H,000H,004H,062H,094H,010H,020H,004H
DB 008H,004H,000H,041H,004H,022H,002H,004H,000H,005H,082H,094H,010H,0A0H,004H,008H
DB 014H,000H,041H,004H,039H,0C7H,0FEH,000H,014H,002H,094H,010H,0A0H,004H,008H,014H
DB 000H,041H,004H,039H,0C7H,0FEH,000H,015H,082H,00CH,010H,040H,003H,0F8H,008H,000H
DB 043H,004H,020H,082H,002H,000H,008H,002H,00CH,010H,040H,003H,0F8H,008H,000H,043H
DB 004H,020H,082H,002H,000H,00DH,080H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,001H,080H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,001H,080H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,001H
DB 080H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,020H
DB 010H,080H,004H,000H,000H,040H,010H,000H,001H,000H,010H,000H,004H,000H,020H,010H
DB 080H,004H,000H,000H,040H,010H,000H,001H,000H,010H,000H,001H,081H,024H,010H,080H
DB 004H,000H,0FFH,0E0H,010H,047H,0BFH,080H,090H,01FH,0FEH,001H,024H,010H,080H,004H
DB 000H,0FFH,0E0H,010H,047H,0BFH,080H,090H,01FH,0FDH,0FDH,024H,057H,0F8H,004H,020H
DB 000H,087H,0FFH,0E4H,0A1H,000H,090H,000H,004H,07DH,024H,057H,0F8H,004H,020H,000H
DB 087H,0FFH,0E4H,0A1H,000H,090H,000H,005H,091H,0FCH,050H,080H,07FH,0F0H,001H,000H
DB 020H,004H,0BFH,001H,008H,000H,024H,011H,0FCH,050H,080H,07FH,0F0H,001H,000H,020H
DB 004H,0BFH,001H,008H,000H,005H,090H,000H,078H,080H,044H,020H,006H,000H,041H,005H
DB 021H,002H,008H,03FH,0F4H,010H,000H,078H,080H,044H,020H,006H,000H,041H,005H,021H
DB 002H,008H,03FH,0F5H,093H,0FEH,097H,0FCH,044H,020H,004H,020H,0FFH,085H,021H,004H
DB 004H,000H,004H,013H,0FEH,097H,0FCH,044H,020H,004H,020H,0FFH,085H,021H,004H,004H
DB 000H,005H,0FCH,040H,090H,020H,07FH,0E3H,0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH
DB 0C4H,07CH,040H,090H,020H,07FH,0E3H,0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH,0C5H
DB 093H,0FCH,018H,020H,044H,020H,004H,002H,07FH,004H,0A8H,090H,041H,008H,044H,013H
DB 0FCH,018H,020H,044H,020H,004H,002H,07FH,004H,0A8H,090H,041H,008H,045H,092H,094H
DB 037H,0FCH,044H,020H,004H,004H,041H,004H,0A9H,000H,080H,008H,044H,012H,094H,037H
DB 0FCH,044H,020H,004H,004H,041H,004H,0A9H,000H,080H,008H,045H,092H,094H,0D2H,020H
DB 07FH,0E0H,004H,000H,07FH,006H,0AAH,000H,090H,00FH,0C4H,012H,094H,0D2H,020H,07FH
DB 0E0H,004H,000H,07FH,006H,0AAH,000H,090H,00FH,0C5H,09AH,094H,011H,020H,044H,000H
DB 004H,000H,041H,005H,024H,001H,008H,008H,044H,01AH,094H,011H,020H,044H,000H,004H
DB 000H,041H,005H,024H,001H,008H,008H,045H,0E2H,094H,010H,020H,004H,008H,004H,000H
DB 041H,004H,022H,002H,004H,000H,004H,062H,094H,010H,020H,004H,008H,004H,000H,041H
DB 004H,022H,002H,004H,000H,005H,082H,094H,010H,0A0H,004H,008H,014H,000H,041H,004H
DB 039H,0C7H,0FEH,000H,014H,002H,094H,010H,0A0H,004H,008H,014H,000H,041H,004H,039H
DB 0C7H,0FEH,000H,015H,082H,00CH,010H,040H,003H,0F8H,008H,000H,043H,004H,020H,082H
DB 002H,000H,008H,002H,00CH,010H,040H,003H,0F8H,008H,000H,043H,004H,020H,082H,002H
DB 000H,009H,080H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,001H
DB 080H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,020H,010H,080H,004H,000H
DB 000H,040H,010H,000H,001H,000H,010H,000H,001H,081H,024H,010H,080H,004H,000H,0FFH,0E0H
DB 010H,047H,0BFH,080H,090H,01FH,0FEH,001H,024H,010H,080H,004H,000H,0FFH,0E0H,010H
DB 047H,0BFH,080H,090H,01FH,0FDH,0FDH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H

DB 0A1H,000H,090H,000H,004H,07DH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H
DB 000H,090H,000H,005H,091H,0FCH,050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H
DB 008H,000H,024H,011H,0FCH,050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H
DB 000H,005H,090H,000H,078H,080H,044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH
DB 0F4H,010H,000H,078H,080H,044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F5H
DB 093H,0FEH,097H,0FCH,044H,020H,004H,020H,0FFH,085H,021H,004H,004H,000H,004H,013H
DB 0FEH,097H,0FCH,044H,020H,004H,020H,0FFH,085H,021H,004H,004H,000H,005H,0FCH,040H
DB 090H,020H,07FH,0E3H,0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH,0C4H,07CH,040H,090H
DB 020H,07FH,0E3H,0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH,0C5H,093H,0FCH,018H,020H
DB 044H,020H,004H,002H,07FH,004H,0A8H,090H,041H,008H,044H,013H,0FCH,018H,020H,044H
DB 020H,004H,002H,07FH,004H,0A8H,090H,041H,008H,045H,092H,094H,037H,0FCH,044H,020H
DB 004H,004H,041H,004H,0A9H,000H,080H,008H,044H,012H,094H,037H,0FCH,044H,020H,004H
DB 004H,041H,004H,0A9H,000H,080H,008H,045H,092H,094H,0D2H,020H,07FH,0E0H,004H,000H
DB 07FH,006H,0AAH,000H,090H,00FH,0C4H,012H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH
DB 006H,0AAH,000H,090H,00FH,0C5H,09AH,094H,011H,020H,044H,000H,004H,000H,041H,005H
DB 024H,001H,008H,008H,044H,01AH,094H,011H,020H,044H,000H,004H,000H,041H,005H,024H
DB 001H,008H,008H,045H,0E2H,094H,010H,020H,004H,008H,004H,000H,041H,004H,022H,002H
DB 004H,000H,004H,062H,094H,010H,020H,004H,008H,004H,000H,041H,004H,022H,002H,004H
DB 000H,005H,082H,094H,010H,0A0H,004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H
DB 014H,002H,094H,010H,0A0H,004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,015H
DB 082H,00CH,010H,040H,003H,0F8H,008H,000H,043H,004H,020H,082H,002H,000H,008H,002H
DB 00CH,010H,040H,003H,0F8H,008H,000H,043H,004H,020H,082H,002H,000H,009H,080H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,001H,080H,020H,010H,080H,004H,000H,000H,040H
DB 010H,000H,001H,000H,010H,000H,004H,000H,020H,010H,080H,004H,000H,000H,040H,010H
DB 000H,001H,000H,010H,000H,001H,081H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H
DB 0BFH,080H,090H,01FH,0FEH,001H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H,0BFH
DB 080H,090H,01FH,0FDH,0FDH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H
DB 090H,000H,004H,07DH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H,090H
DB 000H,005H,091H,0FCH,050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H
DB 024H,011H,0FCH,050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H,005H
DB 090H,000H,078H,080H,044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F4H,010H
DB 000H,078H,080H,044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F5H,093H,0FEH
DB 097H,0FCH,044H,020H,004H,020H,0FFH,085H,021H,004H,004H,000H,004H,013H,0FEH,097H
DB 0FCH,044H,020H,004H,020H,0FFH,085H,021H,004H,004H,000H,005H,0FCH,040H,090H,020H
DB 07FH,0E3H,0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH,0C4H,07CH,040H,090H,020H,07FH
DB 0E3H,0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH,0C5H,093H,0FCH,018H,020H,044H,020H
DB 004H,002H,07FH,004H,0A8H,090H,041H,008H,044H,013H,0FCH,018H,020H,044H,020H,004H
DB 002H,07FH,004H,0A8H,090H,041H,008H,045H,092H,094H,037H,0FCH,044H,020H,004H,004H
DB 041H,004H,0A9H,000H,080H,008H,044H,012H,094H,037H,0FCH,044H,020H,004H,004H,041H
DB 004H,0A9H,000H,080H,008H,045H,092H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H
DB 0AAH,000H,090H,00FH,0C4H,012H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H,0AAH
DB 000H,090H,00FH,0C5H,09AH,094H,011H,020H,044H,000H,004H,000H,041H,005H,024H,001H
DB 008H,008H,044H,01AH,094H,011H,020H,044H,000H,004H,000H,041H,005H,024H,001H,008H
DB 008H,045H,0E2H,094H,010H,020H,004H,008H,004H,000H,041H,004H,022H,002H,004H,000H
DB 004H,062H,094H,010H,020H,004H,008H,004H,000H,041H,004H,022H,002H,004H,000H,005H
DB 082H,094H,010H,0A0H,004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,014H,002H
DB 094H,010H,0A0H,004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,015H,082H,00CH
DB 010H,040H,003H,0F8H,008H,000H,043H,004H,020H,082H,002H,000H,008H,002H,00CH,010H
DB 040H,003H,0F8H,008H,000H,043H,004H,020H,082H,002H,000H,009H,080H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,001H,080H,020H,010H,080H,004H,000H,000H,040H
DB 010H,000H,001H,000H,010H,000H,004H,000H,020H,010H,080H,004H,000H,000H,040H,010H
DB 000H,001H,000H,010H,000H,001H,081H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H

DB 0BFH,080H,090H,01FH,0FEH,001H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H,0BFH
DB 080H,090H,01FH,0FDH,0FDH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H
DB 090H,000H,004H,07DH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H,090H
DB 000H,005H,091H,0FCH,050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H
DB 024H,011H,0FCH,050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H,005H
DB 090H,000H,078H,080H,044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F4H,010H
DB 000H,078H,080H,044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F5H,093H,0FEH
DB 097H,0FCH,044H,020H,004H,020H,0FFH,085H,021H,004H,004H,000H,004H,013H,0FEH,097H
DB 0FCH,044H,020H,004H,020H,0FFH,085H,021H,004H,004H,000H,005H,0FCH,040H,090H,020H
DB 07FH,0E3H,0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH,0C4H,07CH,040H,090H,020H,07FH
DB 0E3H,0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH,0C5H,093H,0FCH,018H,020H,044H,020H
DB 004H,002H,07FH,004H,0A8H,090H,041H,008H,044H,013H,0FCH,018H,020H,044H,020H,004H
DB 002H,07FH,004H,0A8H,090H,041H,008H,045H,092H,094H,037H,0FCH,044H,020H,004H,004H
DB 041H,004H,0A9H,000H,080H,008H,044H,012H,094H,037H,0FCH,044H,020H,004H,004H,041H
DB 004H,0A9H,000H,080H,008H,045H,092H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H
DB 0AAH,000H,090H,00FH,0C4H,012H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H,0AAH
DB 000H,090H,00FH,0C5H,09AH,094H,011H,020H,044H,000H,004H,000H,041H,005H,024H,001H
DB 008H,008H,044H,01AH,094H,011H,020H,044H,000H,004H,000H,041H,005H,024H,001H,008H
DB 008H,045H,0E2H,094H,010H,020H,004H,008H,004H,000H,041H,004H,022H,002H,004H,000H
DB 004H,062H,094H,010H,020H,004H,008H,004H,000H,041H,004H,022H,002H,004H,000H,005H
DB 082H,094H,010H,0A0H,004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,014H,002H
DB 094H,010H,0A0H,004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,015H,082H,00CH
DB 010H,040H,003H,0F8H,008H,000H,043H,004H,020H,082H,002H,000H,008H,002H,00CH,010H
DB 040H,003H,0F8H,008H,000H,043H,004H,020H,082H,002H,000H,009H,080H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,001H,080H,020H,010H,080H,004H,000H,000H,040H,010H,000H
DB 001H,000H,010H,000H,004H,000H,020H,010H,080H,004H,000H,000H,040H,010H,000H,001H
DB 000H,010H,000H,001H,081H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H,0BFH,080H
DB 090H,01FH,0FEH,001H,024H,010H,080H,004H,000H,0FFH,0E0H,010H,047H,0BFH,080H,090H
DB 01FH,0FDH,0FDH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H,090H,000H
DB 004H,07DH,024H,057H,0F8H,004H,020H,000H,087H,0FFH,0E4H,0A1H,000H,090H,000H,005H
DB 091H,0FCH,050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H,024H,011H
DB 0FCH,050H,080H,07FH,0F0H,001H,000H,020H,004H,0BFH,001H,008H,000H,005H,090H,000H
DB 078H,080H,044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F4H,010H,000H,078H
DB 080H,044H,020H,006H,000H,041H,005H,021H,002H,008H,03FH,0F5H,093H,0FEH,097H,0FCH
DB 044H,020H,004H,020H,0FFH,085H,021H,004H,004H,000H,004H,013H,0FEH,097H,0FCH,044H
DB 020H,004H,020H,0FFH,085H,021H,004H,004H,000H,005H,0FCH,040H,090H,020H,07FH,0E3H
DB 0FFH,0F1H,041H,004H,0BFH,008H,043H,08FH,0C4H,07CH,040H,090H,020H,07FH,0E3H,0FFH
DB 0F1H,041H,004H,0BFH,008H,043H,08FH,0C5H,093H,0FCH,018H,020H,044H,020H,004H,002H
DB 07FH,004H,0A8H,090H,041H,008H,044H,013H,0FCH,018H,020H,044H,020H,004H,002H,07FH
DB 004H,0A8H,090H,041H,008H,045H,092H,094H,037H,0FCH,044H,020H,004H,004H,041H,004H
DB 0A9H,000H,080H,008H,044H,012H,094H,037H,0FCH,044H,020H,004H,004H,041H,004H,0A9H
DB 000H,080H,008H,045H,092H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H,0AAH,000H
DB 090H,00FH,0C4H,012H,094H,0D2H,020H,07FH,0E0H,004H,000H,07FH,006H,0AAH,000H,090H
DB 00FH,0C5H,09AH,094H,011H,020H,044H,000H,004H,000H,041H,005H,024H,001H,008H,008H
DB 044H,01AH,094H,011H,020H,044H,000H,004H,000H,041H,005H,024H,001H,008H,008H,045H
DB 0E2H,094H,010H,020H,004H,008H,004H,000H,041H,004H,022H,002H,004H,000H,004H,062H
DB 094H,010H,020H,004H,008H,004H,000H,041H,004H,022H,002H,004H,000H,005H,082H,094H
DB 010H,0A0H,004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,014H,002H,094H,010H
DB 0A0H,004H,008H,014H,000H,041H,004H,039H,0C7H,0FEH,000H,015H,082H,00CH,010H,040H
DB 003H,0F8H,008H,000H,043H,004H,020H,082H,002H,000H,008H,002H,00CH,010H,040H,003H
DB 0F8H,008H,000H,043H,004H,020H,082H,002H,000H,009H,080H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,001H,080H,000H,000H,000H,000H,000H,000H,000H,000H,000H

```
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,001H,080H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H,000H
DB 000H,001H,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH
DB 0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH,0FFH
```

```
;    LJMPL    MAIN
```

```
END
```